



NOTE:

first mount part #1 to your base
Parts 9, 4, 5, 7, 8, and 3 must be assembled second
then slide part #2 onto part #3
screw part #11 onto part 3
place a flat washer between your spring and part #1
finally put part #10 onto part #11

REMEMBER, do not force things together!!

your engine should run very smooth by hand
before putting air pressure to it